

RH2W

RHODIUM READY TO USE PLATING BATH 2G/L WHITE COLOR

DESCRIPTION

RH2W is a ready-to-use white rhodium plating solution. This electrolyte is intended for the deposition of brilliant white, very light, bright coatings. The deposition speed is slower than other formulations allowing for accurate consumption control. This balanced deposit also makes it an ideal choice for larger or flat surface permitting complete surface coverage in low current densities areas. The rhodium plating solution RH2W is efficient at room-low temperatures allowing minimal water evaporation. It is particularly suitable for the rhodium plating of jewelry, watches, spectacle frames and other decorative purposes. The usual coating thickness is ranging from 0.02 up to 0.2 microns.

- For decorative applications
- Brilliant-white, very light coatings
- Up to 0.2 microns coating thickness
- For both rack and barrel plating

DEPOSIT DATA

Purity (%)	99.9
Hardness [HV 0.01]	800 - 900
Density [g/cm ³]	12.4
Thickness from-to [µm]	0.02 - 0.20
Aspect	Shiny
Color	white

PRODUCT FORM

Metal concentration	2 g Rh/l
Product pH	Acidic
Format	Ready to use liquid
Color of the product	Yellow - orange
Storage time	2 years
Volume	1 L

PRODUCT USAGE	RANGE	OPTIMAL
Voltage [V]	2 - 6	3
Current density [A/dm ²]	0.5 - 10	3
Working temperature [°C]	20 - 60	40 - 50
Treatment time [sec]	20 - 60	40
Cathodic efficiency [mg/Amin]	4 - 8	6
Anode/cathode ratio	1:1 - 4:1	2:1
Anode type	Ti/Pt	
Stirring	Moderate	

METAL CONCENTRATION g/l

METAL (g/l)	RANGE	OPTIMAL
Rh	0.4 – 2.0	2.0

COLOR COORDINATES

L *	88.6
a*	0.6
b*	2.1
c*	2.2

Note: Color coordinates here reported have been measured on a white underlayer and they are to be intended as PURELYINDICATIVE being strongly dependent on underlayer color, on thickness of the deposit and on specific design(shape)of the surface.

RELATED PRODUCTS - MAINTAINING

RH5RW.100ML*	Rhodium W replenisher 5 g/100ml - 100 ml
BRITENER1.1L	Brightener additive for rhodium - 1 L

* Product which is subject to the international regulations concerning transportation of dangerous goods

USER GUIDE**READY TO USE SOLUTION PREPARATION**

RH2W is a ready-to-use plating solution at the concentration of 2 g/l. No preparation is required. Pour it directly into working tank, heat it up to the preset temperature and once reached start to plate.

ANODES

Use Titanium Platinized anodes with a layer in platinum not lower than 1.5 µm.

WORKING TANK MATERIALS

For small volume amount solutions-in beaker scale - use Pyrex glass; vice versa use PP /PVC/HDPE tanks for larger volumes and equipped with an efficient exhaust fume/suction or aspiration system (generation of mists diffused by gaseous hydrogen development also can be irritant if inhaled or with allergenic effects).

DC POWER - RECTIFIER

Use a current DC rectifier having an alternate current residue –ripple– less than 5% and having an output amperage enough to obtain a proper electroplating process. The rectifier should be equipped with:

- Amperemeter
- Voltmeter
- Ampere/minutes counter (for bigger installations only).

HEATING SYSTEM

The admitted materials for heaters are Pyrex, quartz or PTFE.

FILTRATION AND MOVEMENT

For bigger plating installations (>5 liters) it is advisable to keep the plating solution continuously filtered and in movement through a magnetic driven filter pump with 5-15 µm cartridges in PP that must have been previously conditioned by boiling them for at least 3 hours and then washed with DI water in order to prevent any possible organic contamination.

PLATING SOLUTION MAINTENANCE

Small-sized of Rh bath (until 5 liters) can be used until the rhodium solution is completely exhausted without adding any rhodium concentrate replenisher solution. For larger volumes use RH5RW replenisher solution to restore the optimal rhodium concentration. For perfect electrolyte performance it is advisable to maintain the rhodium concentration at values not lower than 80% of the initial concentration: i.e. with a plating Rh solution as RH2W working at 2 g/l, additions should be done after a consumption of not more than 0.4 g/l of Rh. Keep always in mind that at optimum conditions a bath working at 2 g/l deposits about 6-10 mg of Rh per ampereminute. Given the cost of rhodium and to have a precise evaluation of the metal consumption it is always advisable to run periodic analytical checks of both Rh and free sulphuric acid content.

ALWAYS USE RH5RW REPLENISHER SOLUTION TO RESTORE THE RHODIUM CONTENT.

ABOUT CONTAMINATS

For a longer life of the rhodium plating solution avoid any possible metallic contaminant particularly: Silver (Ag), Copper (Cu) and Zinc (Zn). If the plating solution will result contaminated by organic pollutants it is advisable to run an active carbon treatment. by adding 2 g/l of carbon into the plating solution to be purified. Stir for 2 hours at a working temperature and filter it off. The important organic components withdrawn from the rhodium electrolyte after an active carbon treatment or even after several drag-out steps can be easily restored by addition of BRITENER1 replenisher (see related technical chart). BRITENER1 has to be added in the rhodium plating solution only in these two cases:

- A) after filtration through active carbon.
- B) after our technical service suggestion.

RH2W

RHODIUM READY TO USE PLATING BATH 2G/L WHITE COLOR

PRETREATMENTS

The ready to use solution RH2W can be directly deposited on Gold, Silver, Palladium, and palladium alloys. For all the other metals (i.e. Copper and its alloys) it is necessary to make an intermediate deposit (strike) of precious metal especially to prevent any contamination for the plating solution from other metallic species like i.e. copper and zinc. All base metals that can suffer passivation over time must be reactivated before the application of the ready to use solution RH2W. As pre-treatment it is suggested to run a preliminary degreasing through a cycle of ultrasonic degreasing treatment -solution followed by a wash step into running water. Then proceed with the electrolytic degreasing step by using the alkaline degreasing solution SGR1. Once the items has been washed again in demineralized water, then proceed in activate and neutralize the surface of the same by dipping them into the slightly acidic solution NEUT1 for 3–4 times subsequently at room temperature, in order to be sure that no any alkaline residues coming from the degreasing previous steps are dragged into the rhodium solution together with the same items to be treated (which would lead to a reduction of its life). After the neutralization, wash in demineralized running water and immerse the pieces in the Rh plating solution for the platingtreatment.

POST TREATMENTS

The electrolyte should be removed from the surface as quick as possible. Wash off the bath residues in a recovery rinse (static rinse). Rinse the parts in circulating deionized water and dry. A possible last rinse in hot static water before dry can help in gain more brightness and luminosity.

WATER PURITY

To prevent contamination of the plating solution during any replenishing operations, use demineralized water with a conductivity of less than 3 $\mu\text{S}/\text{cm}$ (containing no traces of organic compounds, Chlorine, Silicon, or Boron). To achieve maximum deposit quality we suggest to use our high-grade purity WATER.

ITEMS AND PLATING SOLUTION MOVEMENT

Being Rh bath a strong acidic solution, hydrogen bubbles will adhere to the items and must be removed by agitating the solution, by moving the rack or by tapping or knocking on the rack. Otherwise darker stains on the parts may occur. In any case bath agitation by air is not suitable. The movement of the rack can be provided by a cathodic bar movement system at a speed of 5-10 cm/s.

ABOUT pH

pH is < 1 and no control is required for rhodium plating solution. Vice versa is recommended to check periodically the free acid content in ml or g per liter of ready -to-use Rh plating solution by knowing that its value tends to increase with the usage of the plating solution and time (by replenishment).

ABOUT SOLUTION DENSITY

Density raises with the use of the bath (by replenishment).

ABOUT THE APPLIED VOLTAGE

Stay inside the range reported on the Operating Condition Table if possible. If the surface of the items and thus the required current can not be calculated, work with a bath voltage applied which is just sufficient for the minimal evolution of hydrogen gaseous bubbles.

RH2W

RHODIUM READY TO USE PLATING BATH 2G/L WHITE COLOR

DEPOSITION SPEED

The deposition speed is, as reference-guideline- of around 0,025 microns/minute while working at 35°C at 1 A/dm².

ABOUT THE CURRENT DENSITY

The plating of a flash deposit at increased current density is advantageous in some cases when you want to increase the throwing power or when you want to plate on silver or copper alloys in general, also especially onto hollow parts. At this purpose a flash plating at a current 3-4 times higher than normal operating current density is applied for approximately 1 minute (avoidance of passive layers, faster covering also in undercuts and recessions. The evolving hydrogen must be allowed to escape without hindrance).

SAFETY INFORMATION

AVOID ANY DRAG IN OF CYANIDES IN RHODIUM PLATING SOLUTION TO AVOID THE DEVELOPMENT OF HIGHLY TOXIC FUMES!

Being an acidic solution, the electrolyte is corrosive therefore is an irritant to the skin, eyes and mucous membranes. Caution should be exercised when using the product, avoiding contact with the eyes and skin. Use gloves and safety goggles. Keep away from cyanide-based chemicals. For further information please refer to the relative MSDS.

DISCLAIMER

All recommendations and suggestions in this bulletin concerning the use of our products are based upon tests and data believed to be reliable. Since the actual use by others is beyond our control, no guarantee expressed or implied, is made by Legor Group, its subsidiaries or distributors, as to the effects of such use or results to be obtained, nor is any information to be construed as a recommendation to infringe any patent.